


PCI-DIO12

API Manual

Version 1.0



© 2005 DAQ SYSTEM Co., Ltd. All rights reserved.

Microsoft® is a registered trademark; Windows®, Windows NT®, Windows XP®, Windows 7®, Windows 8®, Windows 10®
All other trademarks or intellectual property mentioned herein belongs to their respective owners.

Information furnished by DAQ SYSTEM is believed to be accurate and reliable. However, no responsibility is assumed by DAQ SYSTEM for its use, nor for any infringements of patents or other rights of third parties which may result from its use. No license is granted by implication or otherwise under any patent or copyrights of DAQ SYSTEM.

The information in this document is subject to change without notice and no part of this document may be copied or reproduced without the prior written consent.

Contents

Board Level API Functions

OpenDAQDevice	-----	4
ResetBoard	-----	4
CloseDAQDevice	-----	5

Power Level API Functions

PowerEnable	-----	5
-------------	-------	---

Voltage Function Level API Functions

Init_Voltage	-----	6
Set_Voltage	-----	6
Get_Voltage	-----	7
Set_VoltageHex	-----	7

Logic Level API Functions

Logic_Init	-----	8
Logic_Reset	-----	8
Logic_Start	-----	9
Logic_CheckEnd	-----	9
Logic_GetRepeatSize	-----	9
Logic_Stop	-----	10
Logic_SetData	-----	10
Logic_GetData	-----	10
Logic_SetPort	-----	11
Logic_GetPortData	-----	11
Logic_SetTrigger	-----	11
Logic_Update	-----	12

Clock Level API Functions

Init_Clock	-----	12
Get_Clock	-----	13
Set_Clock	-----	13

PortC Level API Functions

PortC_Init	-----	14
PortC_Reset	-----	14
PortC_Close	-----	15
PortC_Stop	-----	15
PortC_CheckEnd	-----	15
PortC_Start	-----	16
PortC_SetData	-----	16
PortC_SetTrigger	-----	16

PortC Clock Level API Functions

Init_Clock2	-----	17
Get_Clock2	-----	17
Set_Clock2	-----	17

Board Level API Functions

Overview

BOOL	OpenDAQDevice (void)
BOOL	ResetBoard (int nBoard)
BOOL	CloseDAQDevice (void)

OpenDAQDevice

This function opens the device. In the program using the PCI-DIO series board, the device must be opened by calling the function once at the beginning.

BOOL	OpenDAQDevice (void)
-------------	-----------------------------

Parameters:

Return Value:

If device open is successful, the number of devices currently installed in the system (PC) is returned. In case of failure, "-1" is returned.

ResetBoard

This function initializes the device currently installed in the system (PC).

BOOL	ResetBoard (int nBoard)
-------------	--------------------------------

Parameters:

nBoard : Shows the board number currently installed in the system.

The board number is set using the DIP switch of the board.

Return Value:

If the function call fails, "FALSE" is returned.

If the function call succeeds, "TRUE" is returned.

CloseDAQDevice

This function closes all open PCI-DIO series devices. When the use of the device is finished, be sure to close the device so that other programs can use it.

BOOL **CloseDAQDevice (void)**

Parameters:

Return Value:

If the function call fails, "FALSE" is returned.

If the function call succeeds, "TRUE" is returned.

Power Level API Functions

Overview

BOOL **PowerEnable (int nPower, BOOL bEnable)**

PowerEnable

This function selects the power source.

BOOL **PowerEnable (int nPower, BOOL bEnable)**

Parameters:

nPower : '0' is 5V, '1' is LCD power (2.8V), '2' is I/O power (1.8V)

bEnable : 'ON' : True, 'OFF' : False.

Return Value:

If the function call fails, "FALSE" is returned.

If the function call succeeds, "TRUE" is returned.

Voltage Function Level APIs

Overview

BOOL	Init_Voltage (void)
BOOL	Set_Voltage (int nNum, float fVal)
BOOL	Get_Voltage (int nNum, float *fVal)
BOOL	Set_VoltageHex (int nNum, BYTE byVal)

Init_Voltage

This function initializes the voltage of the device currently installed in the system (PC).

BOOL	Init_Voltage (void)
-------------	----------------------------

Parameters :

Return Value :

If the function call fails, "FALSE" is returned.

If the function call succeeds, "TRUE" is returned.

Set_Voltage

This function specifies the voltage value of the device currently installed in the system (PC).

BOOL	Set_Voltage (int nNum, float fVal)
-------------	---

Parameters:

nNum : If '0' is LCD voltage, '1' is I/O voltage.

fVal : Voltage value.

Return Value:

If the function call fails, "FALSE" is returned.

If the function call succeeds, "TRUE" is returned.

Get_Voltage

This function reads the voltage value of the device currently installed in the system (PC).

BOOL Get_Voltage (int nNum, float *fVal)

Parameters:

nNum : If '0' is LCD voltage, '1' is I/O voltage.

fVal : A pointer to the voltage value.

Return Value:

If the function call fails, "FALSE" is returned.

If the function call succeeds, "TRUE" is returned.

Set_VoltageHex

This function designates the device currently installed in the system (PC).

BOOL Set_VoltageHex (int nNum, Byte byVal)

Parameters:

nNum : If '0' is LCD voltage, '1' is I/O voltage.

byVal : Hex value of current system voltage

Return Value:

If the function call fails, "FALSE" is returned.

If the function call succeeds, "TRUE" is returned.

Logic Level APIs

Overview

BOOL	Logic_Init (void)
BOOL	Logic_Reset (void)
BOOL	Logic_Start (DWORD nGenerationSize, BOOL bRepeat)
BOOL	Logic_CheckEnd (void)
BOOL	Logic_GetRepeatSize (DWORD* nRepeatSize)
BOOL	Logic_Stop (void)
BOOL	Logic_SetData (DWORD* nCnt, unsigned char* buf, DWORD nOffset)
BOOL	Logic_GetData (DWORD* nCnt, unsigned char* buf, DWORD nOffset)
BOOL	Logic_SetPort (DWORD* nPort)
BOOL	Logic_GetPortData (DWORD* nCnt, unsigned char* buf)
BOOL	Logic_SetTrigger (BOOL bEnable)
BOOL	Logic_Update (DWORD nGenerationSize)

Logic_Init

This function initializes the logic of PCI-DIO12 board.

BOOL	Logic_Init (void)
------	--------------------------

Parameters :

Return Value :

If the function call fails, "FALSE" is returned.

If the function call succeeds, "TRUE" is returned.

Logic_Reset

This function resets the logic of the current system (PC).

BOOL	Logic_Reset (void)
------	---------------------------

Parameters :

Return Value :

If the function call fails, "FALSE" is returned.

If the function call succeeds, "TRUE" is returned.

Logic_Start

This function starts outputting Data.

BOOL Logic_Start (DWORD nGeneration, BOOL bRepeat)

Parameters:

nGeneration : number of repetitions

bRepeat : "0" : false, "1" : true

Return Value:

If the function call fails, "FALSE" is returned.

If the function call succeeds, "TRUE" is returned.

Logic_CheckEnd

This function examines the logic of the current system (PC) after starting the logic.

BOOL Logic_CheckEnd (void)

Parameters :

Return Value :

If the function call fails, "FALSE" is returned.

If the function call succeeds, "TRUE" is returned.

Logic_Get RepeatSize

This function starts outputting Data.

BOOL Logic_GetRepeatSize (DWORD* nRepeatSize)

Parameters:

bRepeatSize : number of repetitions

Return Value:

If the function call fails, "FALSE" is returned.

If the function call succeeds, "TRUE" is returned.

Logic_Stop

This function stops data output.

BOOL Logic_Stop (void)

Parameters :

Return Value :

If the function call fails, "FALSE" is returned.

If the function call succeeds, "TRUE" is returned.

Logic_SetData

This function saves frame data.

BOOL Logic_SetData (DWORD* nCnt, unsigned char* buf, DWORD nOffset)

Parameters:

nCnt : Specify the memory address to write to

buf : buffer size

nOffset : write offset value

Return Value:

If the function call fails, "FALSE" is returned.

If the function call succeeds, "TRUE" is returned.

Logic_GetData

This function reads a frame.

BOOL Logic_GetData (DWORD* nCnt, unsigned char* buf, DWORD nOffset)

Parameters:

nCnt : Designate the memory address to read

buf : buffer size

nOffset : read offset value

Return Value:

If the function call fails, "FALSE" is returned.

If the function call succeeds, "TRUE" is returned.

Logic_SetPort

This function determines which Port Mode to select.

BOOL Logic_SetPort (DWORD* nPort)

Parameters:

nPort : A, B, C Port

Return Value:

If the function call fails, "FALSE" is returned.

If the function call succeeds, "TRUE" is returned.

Logic_Get PortData

This function gets the Port Data output.

BOOL Logic_GetPortData (DWORD* nCnt, unsigned char* buf)

Parameters:

nCnt : Memory address of 8K byte buffer

buf : Value of 8K byte buffer

Return Value:

If the function call fails, "FALSE" is returned.

If the function call succeeds, "TRUE" is returned.

Logic_SetTrigger

This function enables the trigger.

BOOL Logic_SetTrigger (BOOL bEnable)

Parameters:

bEnable : "0" : false, "1" : true

Return Value:

If the function call fails, "FALSE" is returned.

If the function call succeeds, "TRUE" is returned.

Logic_Update

This function updates the Logic.

BOOL Logic_Update (DWORD nGenerationSize)

Parameters:

nGenerationSize : number of repetitions

Return Value:

If the function call fails, "FALSE" is returned.

If the function call succeeds, "TRUE" is returned.

Clock Level APIs

Overview

BOOL Init_Clock (void)

BOOL Get_Clock (void)

BOOL Set_Clock (DWORD val)

Init_Clock

This function initializes the clock value of Port A.

BOOL Init_Clock (void)

Parameters :

Return Value :

If the function call fails, "FALSE" is returned.

If the function call succeeds, "TRUE" is returned.

Get_Clock

This function reads the clock value of Port A.

BOOL Get_Clock (void)

Parameters: 없음

Return Value:

If the function call fails, "FALSE" is returned.

If the function call succeeds, "TRUE" is returned.

Set_Clock

This function specifies the clock value of Port A.

BOOL Set_Clock (DWORD val)

Parameters:

val : clock value. (initial value 20000000)

Return Value:

If the function call fails, "FALSE" is returned.

If the function call succeeds, "TRUE" is returned.

PortC Level APIs

Overview

BOOL	PortC_Init (void)
BOOL	PortC_Reset (void)
BOOL	PortC_Close (void)
BOOL	PortC_Stop (void)
BOOL	PortC_CheckEnd (void)
BOOL	PortC_Start (DWORD nGeneration, BOOL bRepeat)
BOOL	PortC_SetData (DWORD* nCnt, unsigned char* buf, DWORD nOffset)
BOOL	PortC_SetTrigger (BOOL bEnable)

PortC_Init

This function initializes the clock value of Port c.

BOOL PortC_Init (void)

Parameters :

Return Value :

If the function call fails, "FALSE" is returned.

If the function call succeeds, "TRUE" is returned.

PortC_Reset

This function resets Port C.

BOOL PortC_Reset (void)

Parameters:

Return Value:

If the function call fails, "FALSE" is returned.

If the function call succeeds, "TRUE" is returned.

PortC_Close

This function closes Port C.

BOOL PortC_Close (void)

Parameters:

Return Value:

If the function call fails, "FALSE" is returned.

If the function call succeeds, "TRUE" is returned.

PortC_Stop

This function stops Port C.

BOOL PortC_Stop (void)

Parameters:

Return Value:

If the function call fails, "FALSE" is returned.

If the function call succeeds, "TRUE" is returned.

PortC_Check

This function checks Port C.

BOOL PortC_Check (void)

Parameters:

Return Value:

If the function call fails, "FALSE" is returned.

If the function call succeeds, "TRUE" is returned.

PortC_Start

This function executes Port C as many times as specified.

BOOL PortC_Start (DWORD nGeneration, BOOL bRepeat)

Parameters:

nGeneration : number of repetitions

bRepeat : "0" : false, "1" : true

Return Value:

If the function call fails, "FALSE" is returned.

If the function call succeeds, "TRUE" is returned.

PortC_SetData

This function reads Port C.

BOOL PortC_SetData (DWORD* nCnt, unsigned char* buf, DWORD nOffset)

Parameters:

nCnt : Designate the memory address to read

buf : buffer size

nOffset : read offset value

Return Value:

If the function call fails, "FALSE" is returned.

If the function call succeeds, "TRUE" is returned.

PortC_SetTrigger

This function enables the trigger of Port C.

BOOL PortC_SetTrigger (BOOL bEnable)

Parameters:

bEnable : "0" : false, "1" : true

Return Value:

If the function call fails, "FALSE" is returned.

If the function call succeeds, "TRUE" is returned.

PortC Clock Level APIs

Overview

BOOL **Init_Clock2 (void)**
BOOL **Get_Clock2 (void)**
BOOL **Set_Clock2 (DWORD val)**

Init_Clock2

This function initializes the clock of Port C.

BOOL **Init_Clock2 (void)**

Parameters :

Return Value :

If the function call fails, "FALSE" is returned.

If the function call succeeds, "TRUE" is returned.

Get_Clock2

This function reads the clock value of Port C. (initial value 10000000)

BOOL **Get_Clock2 (void)**

Parameters:

Return Value:

If the function call fails, "FALSE" is returned.

If the function call succeeds, "TRUE" is returned.

Set_Clock2

This function specifies the clock value of Port C.

BOOL **Set_Clock2 (DWORD val)**

Parameters:

val : clock value.

Return Value:

If the function call fails, "FALSE" is returned.

If the function call succeeds, "TRUE" is returned.

Memo

Contact Point

Web sit : <https://www.daqsystem.com>

Email : postmaster@daqsystem.com

